





Hartland Locomotive Works

Wire color code



Note: Orange Wire goes straight to unit
Purple wire goes to switch in tender first.



Note: On some early production models
the light wires are smaller Red and Black
than the motor leads.